Rainbow



SAFETY ISSUES

Avoid sharing this personal object with others due to hygiene concerns.

Stop using this device immediately if you feel uncomfortable when using it.

Only water based lubricant is recommended to use with this product.

Be cautious when using your device for anal insertion.

Stop using this device if its tip is chipped or broken or has sharp edges.

Do not use massage oils or hand cream as lubricants for this device, as you will damage its silicone soft touch surface.

Please keep this device out of children's reach.

HOW TO USE

- 1 Please charge fully before first use.
- 2 The use of a condom with this device is highly recommended.
- 3 Press the POWER button for three seconds to turn on. At this point, only the LED light will activate.
- 4 When the device is on, to engage any program please press the MINUS(-) or PLUS(+) button promptly. In total you can choose one from eight different programs.
- 5 Press the MICROPHONE button to activate the sound responsive feature. The vibration will then stop and the device will only activate when registering an ambient sound (voice or music). Press it again to make the LED light flash in different colors.
- 6 To turn off your vibrator please press the POWER button for 3 seconds.

PRODUCT BRIEF

The streamline is specifically designed to fit perfectly with a woman's intimate anatomy in mind for maximum comfort!

The RAINBOW will charge for 2 hours with a flashing green LED light. The flashing red LED light means that the vibrator needs to be charged.

100% waterproof and super silent, the RAINBOW will allows you to enjoy up to 1.5 hours of ultimate pleasure.

NV TOYS * USER MANUAL

The medical grade silicone and ABS used for all NV Toys intimate vibrators gives you the assurance that these products are totally safe for your body, and the velvet finish give you that extra soft touch!

SPECIFICATIONS

User: Female

Battery type: Li-ion

Number of pulsation modes: 8 Tri-band frequency vibration sensors

User time: More than 1.5 hours Water resistant: 100% waterproof

Materials: Silicone + ABS

CONTROLS

1 - Press ON/OFF button for 3 seconds to turn the device on.

- 2 Press the MINUS(-) or PLUS(+) button to select one of the 8 available vibration modes (ABS part).
- 3 Press the MICROPHONE button to activate the sound responsive feature.
- 4 Signal LED light:

Device ON: Red light ON

Low battery (Charging required): Red light flashes

Charging: Green light flashes

Charging completed (Battery full): Green light ON

SERVICE

Your NV Toys Vibrator is an extremely well designed and assembled device, using only the best materials on the market and should procure you many years of pure worry free pleasure.

However, if you experience any problems or factory/assembly defects or you need additional information to operate your device, please contact our service department and we will do our best to solve your issues as soon as possible.

Caution: please do not take your vibrator apart by yourself or by an unauthorized repair shop, as your warranty will automatically expire.

DISCLAIMER

Users of this device are doing so at their own risk. Neither NV Toys nor its retailers are responsible for any injury caused by the use of this product. This is to be used as a novelty item only!

This product doesn't claim to cure any disease or STI.

CLEANING AND STORAGE

Always clean your NV Toys device thoroughly before and after each use.

Clean your device with an antibacterial toy cleaner.

Hard detergents, disinfectants, acetone or 75% alcohol are not recommended to clean your device.

Avoid direct sunlight and air drying your device.

Store your device in a clean and dry space, and avoid leaving it in contact with other silicone or TPR devices, as this could affect the properties of the high grade ABS of your device.